

4F Series Engine Electric System

Installation Guide



4F Series Engine Electric System Installation Guide	1
Update History	3
1. System introduction	4
1.1. Fuel system:	4
1.2. ECU:	4
2. Sensors	5
2.1. Water sensor	5
2.2. Oil pressure sensor	5
2.3. Speed sensor	5
3. Alternator, starter introduction	6
3.1. Alternator	6
3.1.1 Marine Alternator	7
3.2 Starter	8
3.2.1 Marine starter	9
3.3.1 Introduction to post-processing system	10
3.3.2 Post processing usage	11
4. Usage requirements (must read)	14
4.1 Starter rely:	14
4.2 Panel requirements: (important)	15
4.2.1 Basic Introduction	15
4.2.2 Battery and Mainline Requirements (Recommended)	16
4.2.3 Requirements for marine engine batteries	18
5. Common electrical system faults	19
5.1 Battery loss	19
5.2 Engine cannot stop	19
5.3 The generator panel cannot control the shutdown	20
5.4 Alternator doesn't generate electricity	20
5.5 Post processor failure	21
5.6 Important parts installation instructions	22
5.6.1 Alternator wiring	22
5.6.2 Starter Wiring	23
6. Installation and wiring precautions	24
6.1 The wiring locations of battery+ and battery - on the engine harness	24
6.2 Alternator wiring	25
6.3 Engine harness and instrument wiring	25
6.4 Check the preheating plug	27

Appendix 1:


12V ECU Electrical System Schematic Diagram **Wiring harness installation guide**

Update History

Version	Date	Author	Updates	
1.0	2019/07/17	HWL	Created	N/A
1.1	2019/12/25	HWL	Increase differences in ship machinery	N/A
1.2	2020/08/01	YUE GANG	Add 32-bit system and wiring guidance	N/A
1.3	2021/01/19	YUE GANG	Add fault information	N/A
1.4	2021/01/21	-	Installation and wiring precautions	N/A
1.5	2023/07/24	CYX	Modify the wiring instructions and successful startup conditions of the ship's engine	N/A


1.System introduction

1.1.Fuel system:



Note: For the 4F series, the ECU only controls the oil pump oil quantity, which is the transmission control signal at the position indicated in the figure.

1.2.ECU:




MD1CC878

ECU Shape

Note: The 12V ECU has 154pin.

2.Sensors

2.1.Water sensor



The temperature sensor is composed of NTC thermistors, and the resistance value of the thermistor changes with the temperature of the coolant, causing the voltage output of the sensor to also change. The ECU calculates the current coolant temperature value based on the collected signal, mainly used for cold start control.

2.2.Oil pressure sensor



Oil pressure sensor: VDO 10Bar

Engine oil temperature alarm value: $-40\sim 125\text{ }^{\circ}\text{C}$, the alarm value is set on the instrument according to requirements

Installation thread: NPT 1/4

Output the oil pressure signal to the ECU, and finally feedback it to the instrument through CAN communication, which is displayed in digital form

4. AD 端电压输出 (电源电压 5V 时):

表压力 (MPa)	0	0.4
AD 电压 (V)	0.710 ± 0.07	2.59 ± 0.06

5. T 端电阻输出 (测试电流小于 1mA, 温度平衡时间大于 10min):

温度 ($^{\circ}\text{C}$)	-10	20	80
电阻 (Ω)	$9.365\text{k}\pm 0.565\text{k}$	$2.51\text{k}\pm 0.1\text{k}$	322 ± 10


2.3.Speed sensor



Speed sensor (optional):


Installation thread: M18X1.5

Installation distance: generally 0.7-1mm from the flying gear teeth



3. Alternator, starter introduction


3.1. Alternator



Note: The land generator set has provided excitation wires on the engine harness; The generator is not self-excited, and the IG signal is normally energized in the ON position.

3.1.1 Marine Alternator


Special note: Due to market demand, the marine alternator is a dual wire system, and the negative electrode needs to be grounded. The negative electrode B- of the marine alternator is led out with a bolt and not connected to the engine casing. The details are as follows



Requirement: In addition to the grounding of the land alternator, the negative pole of the marine alternator also needs to be directly connected to the main switch of the battery negative pole, otherwise the generator cannot generate electricity normally. The recommended wire diameter from generator B+ to battery charging line is 10mm^2 (Adjustable according to generator current and

distance)

3.2 Starter




12V Starter electromagnetic switch current: 45-60A

24V Starter electromagnetic switch current: 25-30A

3.2.1 Marine starter


Special note: Due to market demand, the marine starter is a dual wire system, and the negative pole needs to be grounded. The negative pole B- of the marine starter is led out with a bolt and not connected to the engine casing. The details are as follows



Requirements:

1. On the basis of land based starters, the negative pole B- of marine starters needs to be directly connected to the battery negative pole main switch.
2. The general configuration of the marine engine is as shown in the figure with a starting relay, which can also be directly controlled by the customer by installing a new relay (refer to the following three requirements for details)

3.3.1 Introduction to post-processing system



The post-treatment system is an exhaust gas treatment system that achieves emission requirements by adsorbing impurities in the exhaust gas. The post-processing device includes three sensors: DOC exhaust temperature sensor, DPF exhaust temperature sensor, and differential pressure sensor.

The above three sensors have been integrated together at the marked plug position to avoid incorrect connection.

Pressure difference sensor: The pressure difference sensor is used to measure the pressure values before and after DPF, and the pressure

difference result is an important basis for judging the quality of DPF and whether regeneration is successful.

3.3.2 Post processing usage

K87B	DPF power output	(再生开关电源输出)
K16	DPF regeneration switch	(再生开关)
K68	Prohibit regeneration power output	(禁止再生开关电源输出)
K15	DPF prohibit regeneration switch	(禁止再生开关)
K73	Indicator power output	(再生提示灯电源输出)
K25	DPF regeneration indicator	(再生提示灯)

If you want to use the regeneration function, you need to connect the functional wire of the vehicle harness shown in the above figure, and connect a switch between the switch wire and the power output.

Preconditions for DPF regeneration activation:

- Engine running time > 10 seconds, water temperature > 65 degrees;
- $100\text{ }^{\circ}\text{C} \geq \text{ambient temperature} \geq -40\text{ }^{\circ}\text{C}$, $100\text{ }^{\circ}\text{C} \geq \text{temperature after intercooling} \geq -40\text{ }^{\circ}\text{C}$;
- 24V engines require a battery voltage greater than 16V, while 12V engines require a battery voltage greater than 11.5V;
- Do not step on the clutch, brake or accelerator;
- The gear position is in neutral, and the vehicle speed is 0;
- The engine speed is greater than 700rpm and less than 3750rpm;

g) T4 and T5 temperatures > 80 °C;

h) If a DPF severe overload fault is reported, carbon cleaning is required before regeneration;

The above are the prerequisites for automatic regeneration and the activation of regeneration function.


In situ parking regeneration:

- 1) When parking for regeneration, you can first step on the accelerator to increase the water temperature to above 70 °C;
- 2) After heating up, keep the vehicle ignition at idle speed and in neutral position. During this period, do not touch the clutch, accelerator, or brake, and ensure that the no regeneration switch button is turned off;
- 3) Press the manual regeneration switch for 5 seconds to activate DPF regeneration. As shown in the figure (special attention should be paid to low speed and short distance vehicles, and the indicator light flashing should be immediately regenerated), during the regeneration period, the vehicle will perform automatic refueling door and other operations;
- 4) At the same time, the vehicle must be parked in an open area without flammable and explosive materials around it, as the exhaust temperature will be above 600 °C at this moment; Do not park in a confined space, as it may pose a safety hazard. Park regeneration takes approximately 30 minutes.


Only when the above conditions are met can the regeneration switch be pressed. Press and hold for a few seconds (2-5 seconds), and release according to the regeneration indicator light, at which point the parking regeneration begins.

The disable regeneration switch button is used to disable automatic regeneration and manual regeneration functions. (This button can only be opened when the regeneration conditions are not met, and it is absolutely prohibited to be opened under normal driving conditions)

Definition of post processor plug:

Pin assignment	Number	Assignment
	1	Differential pressure sensor positive pole
	2	Differential pressure sensor negative pole
	3	Differential pressure sensor signal
	4	DOC temperature signal
	5	DOC temperature sensor negative pole
	6	DPF temperature signal
	7	DPF temperature sensor negative pole

4.Usage requirements （must read）



4.1 Starter rely:

The starting method is relay controlled starting, and the principle is shown in the right figure.

Starter rely $\geq 12\text{V}/60\text{A}; 24\text{V}/40\text{A}$

4.2 Panel requirements: (important)

To prevent damage to the starter due to reverse drag, a panel is used for startup control.

1.1 Condition for determining successful engine start: Speed=350rpm,
Oil pressure=125kPa

1.2 If the engine fails to start for three consecutive times, it should be shut down for a short time to wait for the starter to cool down, and the oil, electricity, and gas circuits should be checked for faults before starting the operation

4.2.1 Basic Introduction


1. The engine ECU adopts CAN communication and follows the J1939 protocol. It can display water temperature, oil pressure, power voltage, and speed, and has a fault code, without connecting to a fault light or charging indicator
2. The ECU power cord in the reserved interface must be connected to the battery terminal as much as possible, and no other electrical appliances except switches are allowed to be connected in the middle
3. If the engine is used as the main engine, please use the Yuchai system standard throttle interface for the throttle

4. Used as a generator set, with the control strategy starting at idle speed and automatically rising to the working speed within 10 seconds without connecting the speed switch

4.2.2 Battery and Mainline Requirements (Recommended)

Battery requirements:

12V System	$\geq 85\text{Ah}$	630CCA
24V System	$\geq 85\text{Ah}$	630CCA*2



It is recommended to increase the battery capacity in high-altitude and cold regions.

Main line requirements for power supply: wire diameter 50-75mm² Above length<2m

Suggestion: Connect the positive wire of the battery to the positive wire B+ of the starter, and connect the negative wire controlled by the main switch directly to the bolt of the flywheel housing. The connection should be firm and reliable. For the selection of the main line diameter, please refer to the following table. The line diameter in the table is only for calculation purposes. Please choose the appropriate line diameter according to the actual situation.

Nominal voltage	Drop Vd/100A	Conditions of Use
12V	0.2	Good/General
24V	0.4	
12V	0.1	Bad
24V	0.17	

The usage conditions in the table are "good", "general", and "bad", which need to be determined by experience based on the degree of impact of the actual usage environment on the engine, including temperature, humidity, vibration, corrosion, and other factors. They are also related to the engine's usage time, area, and purpose

Average starting current	Drop Vd/100A	Conditions of Use	Line length L	1m	2m
300A	0.2	General	Wire	40	50
	0.1	Bad	diameter S (mm ²)	50	75
$S = I * 2L / (54.4 * Vd)$					

4.2.3 Requirements for marine engine batteries

The environmental requirements for the use of marine engines require high electrical performance. It is recommended that customers use large capacity batteries to meet the engine's battery requirements to the greatest extent possible:

12V System $\geq 150\text{Ah}$ 1000CCA

24V System $\geq 150\text{Ah}$ 1000CCA*2

Main line requirements for power supply: wire diameter 50-75mm² The above length is less than 2m.

5.Common electrical system faults

5.1 Battery loss

Generally, starting an engine requires a battery level of 60%-70% or more. Under normal conditions, the static discharge current is very low, and the battery can be stored for more than one month. If the battery loses power in a short period of time, there may be a situation where the electrical appliance continues to discharge. All electrical appliances need to go through the negative main switch. When not in use, the negative main switch can be disconnected to minimize electrical consumption; Check if the engine belt is loose, which may lead to poor engine charging or power loss. Tensioning or replacing the belt is sufficient.

5.2 Engine cannot stop

The engine shutdown is achieved by powering off the A2 signal line; A2 is normally energized during normal operation; If there is a power outage, the machine will shut down. If the machine cannot be stopped, check if the A2 wiring is in the ON position.

5.3 The generator panel cannot control the shutdown

The panel can start and stop the engine normally. But after disconnecting the negative main switch, the instrument cannot be powered off and extinguished. In this situation, the positive and negative poles of the panel are usually directly connected to the positive and negative poles of the battery, without passing through the negative main switch; It is recommended to connect the negative main switch. The reason for this is often due to other electrical appliances applying reverse voltage through the circuit of the monitor when the circuit is complete, which may cause the instrument to fail to turn off. It can be checked by disconnecting the wiring to the instrument one by one.

5.4 Alternator doesn't generate electricity

The normal generator output voltage is around $14 \pm 0.25V$ and 27V, which is slightly higher than the battery voltage.

The conditions for normal operation of the generator: the speed of the generator gear train is greater than 1000rpm; There is an excitation signal, and the excitation requires ON power, and there is always power during operation; The generator B+ should form a complete circuit with the battery; If you believe that the generator is

faulty, please check if the above three conditions are met.

5.5 Post processor failure

1. Remove the differential pressure sensor, check the differential pressure pipe, and confirm if there is any blockage, bending, or air leakage in the differential pressure pipe;

2. Use a multimeter to measure whether there is a 5V voltage between pins 1 and 2 of the differential pressure sensor wiring harness, and whether pin 2 can conduct normally with the ground wire;


3. Disconnect the two differential pressure tubes of the differential pressure sensor, and measure the output voltage of pins 2 and 3 with a multimeter. At this time, the actual pressure difference between the two ends of the differential pressure sensor is "0Kpa", and the voltage measured by the multimeter should be between

4. About 0.50V; Blow air from the front air inlet of the differential pressure sensor with a nozzle, and the voltage measured by the multimeter should be around 1-2V. If the output voltage does not match, it is judged that the differential pressure sensor is damaged;


5. If there are no issues with the above, disassemble the DPF, observe whether the DPF gasket and DPF carrier are damaged, and whether there is obvious ablation of the DPF. If so, replace the DPF.

5.6 Important parts installation instructions

5.6.1 Alternator wiring



5.6.2 Starter Wiring



6. Installation and wiring precautions

6.1 The wiring locations of battery+ and battery - on the engine harness



(Wrong)

(Right)

Attention: The purpose of the above wiring is to avoid excessive voltage drop at the remote end during startup, which may ultimately lead to startup failure. When shutdown for a long time without use, the negative main switch must be turned off to avoid battery feeding (all negative circuits must be controlled by the negative main switch).

6.2 Alternator wiring



6.3 Engine harness and instrument wiring

预留接口

线号	粘贴标识内容	
K54B	comm CAN_H	(CAN通讯_H)
K76B	comm CAN_L	(CAN通讯_L)
K88D	Ignition signal	(点火信号)
K35B	Start signal	(启动信号)
K87B	DPF power output	(再生开关电源输出)
K16	DPF regeneration switch	(再生开关)
K68	Prohibit regeneration power output	(禁止再生开关电源输出)
K15	DPF prohibit regeneration switch	(禁止再生开关)

预留线

线号	粘贴标识内容
A2b	Alternator excitation
L	Charge indicator

(励磁线)
(充电指示灯)

As shown in the above figure:

Connect the CAN communication line to the instrument and read the entire machine information;

The K88D ignition signal is an electrical signal that must be connected to the positive pole;

When the K35B start signal is received from the positive pole, start the machine, ignite it, and disconnect it, which cannot be connected normally.

The regeneration switch and the prohibit regeneration switch are mandatory connections when using post-processing. The connection method is shown in the attached figure.

The A2b excitation line is a necessary connection for the generator. After connecting to the positive pole and the generator B+

to the battery+, charging begins.


The L charging indicator light is used as needed and can be connected to the positive electrode.

6.4 Check the preheating plug



Note: The working time of the preheating plug is controlled by the engine ECU. Firstly, confirm whether the preheating plug is correctly connected during the wiring process; Secondly, whether the preheating relay is working properly.


RAYWIN



RAYWIN POWERTRAIN TECHNOLOGY CO., LTD.

Add: NO.99 JIUJIANG RODE, SHUANGFU DISTRICT, Chongqing, China


Tel: +86 23 85553153



RAYWIN POWERTRAIN TECHNOLOGY CO., LTD.

Add: NO.99 JIUJIANG RODE, SHUANGFU DISTRICT, Chongqing, China

Tel: +86 23 85553153



RAYWIN POWERTRAIN TECHNOLOGY CO., LTD.

Add: NO.99 JIUJIANG RODE, SHUANGFU DISTRICT, Chongqing, China

Tel: +86 23 85553153